



- 1) REMOVE BOLTS AND TABERNACLE
- 2) POSITION SUPPLIED PLATE BETWEEN TABERNACLE AND DECK PAN ALIGNING PLATE HOLES WITH HOLES IN DECK PAN FOR AFT BOLTS
- 3) REPLACE TABERNACLES AND ALL BOLTS (NEW AFT BOLTS WILL BE SUPPLIED)

KIT BILL OF MATERIALS

- 1 - S.S. PLATE PREDRILLED
- 2 - F.H.M.S. 1/4" x 4 1/2"
- 1 - INSTALLATION DIAG. NO. 260-24015 (THIS SHEET)

CAPRI SAILBOATS INC. 21200 VICTORY BLVD. WOODLAND HILLS, CA		DRAWN BY DC
SCALE: —	APPROVED BY: —	REVISED
DATE: 4-14-92		
MAST STEP PLATE INSTALLATION		
CAPRI 26	DRAWING NUMBER 260-24015	